

# MERITOR® ALLFIT BRAKE PADS



|                                                                                                                                                                            |  |  |  |                                                                                                                                                              |  |  |  |                                                                                                                                                                                                                                   |  |  |  |                                                                                                                                                                    |  |  |  |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|--|--|--------------------------------------------------------------------------------------------------------------------------------------------------------------|--|--|--|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|--|--|--------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|--|--|
| <b>B Frame</b>                                                                                                                                                             |  |  |  | <b>Bendix</b>                                                                                                                                                |  |  |  | <b>BPW</b>                                                                                                                                                                                                                        |  |  |  | <b>Brembo</b>                                                                                                                                                      |  |  |  |
| <b>MDP3122</b><br>Iveco<br>MAN<br>Renault<br>Volvo<br>+<br><br>WVA 29122<br>KIT CONTENTS: x4<br>PWVI: Prepared for                                                         |  |  |  | <b>MDP3032K</b><br>Iveco<br><br>WVA 29032<br>KIT CONTENTS: x4<br>PWVI: Prepared for                                                                          |  |  |  | <b>MDP3227K</b><br>BPW Axles<br><br>WVA 29227<br>KIT CONTENTS: x4<br>PWVI: Prepared for                                                                                                                                           |  |  |  | <b>MDP3267K</b><br>BPW Axles<br><br>WVA 29267<br>KIT CONTENTS: x4<br>PWVI: Prepared for                                                                            |  |  |  |
| <b>MDP3181K</b><br>Freuhuf<br>Mercedes<br>Trenkamp & Gehle<br><br>WVA 29147<br>29181<br>29207<br>KIT CONTENTS: x4<br>PWVI: Prepared for                                    |  |  |  | <b>MDP3429K</b><br>Gigant<br>Just<br>SAF<br>Scania<br><br>WVA 29429<br>KIT CONTENTS: x4<br>PWVI: Prepared for                                                |  |  |  | <b>MDP3195K</b><br>SAF<br><br>WVA 29195<br>KIT CONTENTS: x4<br>PWVI: Prepared for                                                                                                                                                 |  |  |  | <b>MDP3498</b><br>Setra (inc. Kässbohrer)<br><br>WVA 29498<br>KIT CONTENTS: x4<br>PWVI: None                                                                       |  |  |  |
| <b>MDP3143K</b><br>Disco<br>Freuhuf<br>Mercedes<br>SAF<br>Sauer<br>Scania<br>Trenkamp & Gehle<br><br>WVA 29120<br>29143<br>29185<br>KIT CONTENTS: x4<br>PWVI: Prepared for |  |  |  | <b>MDP3175K</b><br>Just<br>Kegel<br>Trax<br>Kron<br>SAF<br>Sauer<br>Trenkamp & Gehle<br><br>WVA 29175<br>KIT CONTENTS: x4<br>PWVI: Prepared for              |  |  |  | <b>MDP3415K</b><br>Haldex<br>Kegel<br>Krone<br>SAF<br><br>WVA 29415<br>KIT CONTENTS: x4<br>PWVI: Prepared for                                                                                                                     |  |  |  | <b>MDP3747</b><br>DAF<br>MAN<br>Massey<br>Neoplan<br>Setra<br>Van Hool<br>VDL<br><br>WVA 29147<br>KIT CONTENTS: x8<br>PWVI: None                                   |  |  |  |
| <b>MDP3148K</b><br>MAN<br>Mercedes<br>Renault<br>+<br><br>WVA 29115<br>29116<br>29148<br>29183<br>KIT CONTENTS: x4<br>PWVI: None                                           |  |  |  | <b>MDP3095K</b><br>DAF<br>Iveco<br>MAN<br>Mercedes<br>+<br><br>WVA 29095<br>29197<br>KIT CONTENTS: x4<br>PWVI: Prepared for                                  |  |  |  | <b>MDP3087K</b><br>DAF<br>Iveco<br>MAN<br>Mercedes<br>Renault<br>Scania<br>+<br><br>WVA 29042<br>29059<br>29087<br>29106<br>29108<br>29109<br>29163<br>29179<br>29202<br>29253<br>29331<br>KIT CONTENTS: x4<br>PWVI: Prepared for |  |  |  | <b>MDP3167K</b><br>BPW<br><br>WVA 29167<br>29307<br>KIT CONTENTS: x4<br>PWVI: Prepared for                                                                         |  |  |  |
| <b>MDP3171K</b><br>BPW<br><br>WVA 29138<br>29171<br>29308<br>KIT CONTENTS: x4<br>PWVI: Prepared for                                                                        |  |  |  | <b>MDP3246K</b><br>Mercedes<br><br>WVA 29246<br>KIT CONTENTS: x4<br>PWVI: None                                                                               |  |  |  | <b>MDP3835K</b><br>Alexander Bus<br>Mercedes<br>Neoplan<br>Optare<br>Plaxton<br>Stear<br><br>WVA 29835<br>KIT CONTENTS: x4<br>PWVI: Prepared for                                                                                  |  |  |  | <b>MDP3137K</b><br>ROR<br>SAF<br>Sauer<br>Volvo<br><br>WVA 29137<br>KIT CONTENTS: x4<br>PWVI: None                                                                 |  |  |  |
| <b>MDP3090K</b><br>Iveco<br>Renault<br>Volvo<br>+<br><br>WVA 29090<br>KIT CONTENTS: x4<br>PWVI: Prepared for                                                               |  |  |  | <b>MDP3242K</b><br>SAF<br><br>WVA 29242<br>KIT CONTENTS: x4<br>PWVI: Prepared for                                                                            |  |  |  | <b>MDP3136K</b><br>ROR<br>SAF<br>Sauer<br>Volvo<br><br>WVA 29136<br>KIT CONTENTS: x4<br>PWVI: None                                                                                                                                |  |  |  | <b>MDP3125K</b><br>Caetano<br>Plaxton<br>ROR<br>SAF<br>Sauer<br>Van Hool<br>Volvo<br>Wrightbus<br><br>WVA 29125<br>29277<br>KIT CONTENTS: x4<br>PWVI: Prepared for |  |  |  |
| <b>MDP3043K</b><br>Berhof<br>Caetano<br>Dennis<br>Neoplan<br>Renault<br>Timoney<br><br>WVA 29043<br>KIT CONTENTS: x4<br>PWVI: None                                         |  |  |  | <b>MDP3124K</b><br>Freuhuf<br>ROR<br>SAF<br>Sauer<br><br>WVA 29124<br>29155<br>KIT CONTENTS: x4<br>PWVI: Prepared for                                        |  |  |  | <b>MDP3169K</b><br>Freuhuf<br>SAF<br>Renault<br>SAF<br>Sauer<br>Volvo<br><br>WVA 29169<br>29177<br>KIT CONTENTS: x4<br>PWVI: Prepared for                                                                                         |  |  |  | <b>MDP3174K</b><br>Renault<br>Volvo<br>+<br><br>WVA 29174<br>29218<br>29273<br>KIT CONTENTS: x4<br>PWVI: Prepared for                                              |  |  |  |
| <b>MDP3174KWI</b><br>Renault<br>Volvo<br>+<br><br>WVA 29174<br>29218<br>29273<br>KIT CONTENTS: x4<br>PWVI: Included x2                                                     |  |  |  | <b>MDP3030K</b><br>Iveco<br>MAN<br>Mercedes<br>Renault<br>+<br><br>WVA 29030<br>29083<br>29113<br>KIT CONTENTS: x4<br>PWVI: Prepared for                     |  |  |  | <b>MDP3131K</b><br>Iveco<br>MAN<br>Renault<br>Volvo<br>+<br><br>WVA 29131<br>KIT CONTENTS: x4<br>PWVI: Prepared for                                                                                                               |  |  |  | <b>MDP3173K</b><br>Renault<br>Volvo<br><br>WVA 29173<br>29203<br>KIT CONTENTS: x4<br>PWVI: Prepared for                                                            |  |  |  |
| <b>MDP3077</b><br>DAF<br>Neoplan<br><br>WVA 29077<br>KIT CONTENTS: x4<br>PWVI: Included x2                                                                                 |  |  |  | <b>MDP3024</b><br>Daewoo Trucks<br>DAF<br>Iveco<br><br>WVA 29024<br>KIT CONTENTS: x4<br>PWVI: Included x2                                                    |  |  |  | <b>MDP3088</b><br>DAF<br>Iveco<br>MAN<br>Renault<br>Volvo<br>+<br><br>WVA 29088<br>KIT CONTENTS: x4<br>PWVI: Prepared for                                                                                                         |  |  |  | <b>MDP3126</b><br>DAF<br>Mercedes<br>Renault<br>SAF<br>+<br><br>WVA 29126<br>29159<br>KIT CONTENTS: x4<br>PWVI: Prepared for                                       |  |  |  |
| <b>MDP3126K</b><br>DAF<br>Mercedes<br>Renault<br>SAF<br>+<br><br>WVA 29126<br>29159<br>KIT CONTENTS: x4<br>PWVI: Prepared for                                              |  |  |  | <b>MDP3142</b><br>Renault<br><br>WVA 29142<br>KIT CONTENTS: x4<br>PWVI: Prepared for                                                                         |  |  |  | <b>MDP3162K</b><br>Freuhuf<br>SAF<br>Sauer<br>Schnitz<br>Vale<br>Trenkamp & Gehle<br>York Trailers<br><br>WVA 29162<br>KIT CONTENTS: x4<br>PWVI: Prepared for                                                                     |  |  |  | <b>MDP3142K</b><br>Renault<br><br>WVA 29142<br>KIT CONTENTS: x4<br>PWVI: Prepared for                                                                              |  |  |  |
| <b>MDP3141</b><br>DAF<br>Dennis<br>Freuhuf<br>SAF<br>Sauer<br>Trenkamp & Gehle<br>Volvo<br><br>WVA 29141<br>KIT CONTENTS: x4<br>PWVI: Prepared for                         |  |  |  | <b>MDP3162</b><br>Freuhuf<br>SAF<br>Sauer<br>Schnitz<br>Vale<br>Trenkamp & Gehle<br>York Trailers<br><br>WVA 29162<br>KIT CONTENTS: x4<br>PWVI: Prepared for |  |  |  | <b>MDP3162K</b><br>Freuhuf<br>SAF<br>Sauer<br>Schnitz<br>Vale<br>Trenkamp & Gehle<br>York Trailers<br><br>WVA 29162<br>KIT CONTENTS: x4<br>PWVI: Prepared for                                                                     |  |  |  | <b>MDP3162K</b><br>Freuhuf<br>SAF<br>Sauer<br>Schnitz<br>Vale<br>Trenkamp & Gehle<br>York Trailers<br><br>WVA 29162<br>KIT CONTENTS: x4<br>PWVI: Prepared for      |  |  |  |



ALLFIT

